

**BELL MEDIUM**

**Instruments**

<b>Part number</b>	<b>Alternate Part numbers</b>	<b>Description</b>	<b>Model</b>
111302-5		H.S.I.	212, 412
111303-4		Attitude indicator	212, 412
124.041.1	212-075-036-101	Indicator, Oil Temp / Press	212, 412
124.043		Indicator Hyd Temp / Press	212, 412
124.044		Indicator, Fuel Pressure	212, 412
124.115	209-070-262-009	Indicator, Oil Temp / Press	212
124.115.3	212-070-262-101	Indicator. Oil temp	212, 412
1301-1002	212-070-238-005	Altimeter	412
209-070-262-009	124.115	Indicator, Oil Temp	212
209-070-262-101	209-070-262-111	Indicator. Oil temp	212, 412
209-070-262-111	209-070-262-101	Indicator. Oil temp	212, 412
209-070-263-003		Indicator, Volt	212, 412
209-070-264-003		Ammeter	212, 412
212-070-108-007	212-070-108-103	Triple Tach	212
212-070-108-103	212-070-108-007	Triple Tach	212
212-070-116-009	212-070-116-107	Indicator, XMSN	212, 412
212-070-116-107	212-070-116-009	Indicator, XMSN	212, 412
212-070-160-129FM		Dual Torque	212HP
212-070-238-003	212-070-238-007	Altimeter	212, 412
212-070-238-005	1301-1002	Altimeter	412
212-070-238-007	212-070-237-003	Altimeter	212, 412
212-070-242-003		Indicator, NG	212
212-075-036-101	124.041.1	Indicator, Oil Temp / Press	212, 412
212-075-037-101	212-075-037-105	Indicator, NG	212, 412

**BELL MEDIUM**

**Instruments**

<b>Part number</b>	<b>Alternate Part numbers</b>	<b>Description</b>	<b>Model</b>
212-075-037-105	212-075-037-101	Indicator, NG	212, 412
212-075-067-105	212-075-067-109	Indicator, ITT	212, 412
212-075-067-109	212-075-067-105	Indicator, ITT	212, 412
212-075-420-003	212-075-562-003	Indicator, ITT	212
212-075-562-003	212-075-420-003	Indicator, ITT	212
393008-040		Indicator, Fuel Qty	212, 412
412-075-008-101		Dual Torque	412

**BELL MEDIUM**

**Electrical**

<b>Part Number</b>	<b>Alternate Part number</b>	<b>Description</b>	<b>Model</b>
01-0770285-11	44410-2-24	Strobe Light	212
01-0770285-21	44410-2-24	Strobe Light	212
15-0007-43	90-004-1	Light assy, Cockpit	212
1A250(1D)	PS304-1	Inverter	212
1B250-B212-1661	PS304-1	Inverter	212
209-075-326-001	209-075-326-005	RPM Limit Detector	212
209-075-326-005	209-075-326-001	RPM Limit Detector	212
209-075-326-101	209-075-326-001	RPM Limit Detector	212
209-075-395-001	892121-0350	Amp, Fire Detection	212
214-075-244-001	214-075-244-101	Rate Gyro	212
214-075-244-101	214-075-244-001	Rate Gyro	212
30-326RT1	30-326RT-1	Control Amplifier	212
30-326RT-1	30-326RT1	Control Amplifier	212

**BELL MEDIUM**

Electrical

Part Number	Alternate Part number	Description	Model
44410-2-24	70285-01	Strobe Light	212
70285-01	44410-2-24	Strobe Light	212
892121-0350	209-075-395-001	Amp, Fire Detection	212
90-004-1	15-0007-43	Light assy, Cockpit	212
ASH584-5	PS304-1	Inverter	212
G6250-4	G-6250-4	Landing Light assy	212
G-6250-4	G6250-4	Landing Light assy	212
GG2479AA03	GG2479AB03	Rate Gyro	212
GG2479AB03	GG2479AA03	Rate Gyro	212
MS25358-7		Light assy	212
PC15BC(A)	PS304-1	Inverter	212
PS304-1	ASH584-5	Inverter	212
PS270-1	PS304-1	Inverter	212
51509-002R	613-6	DC control unit	212
613-6	51509-002R	DC control unit	212
51539-002N	51509-002R	DC control unit	212
214-075-150-001	VAAM1422D102125XX001	Relay, Voltage sensing	212
VAAM1422D102125XX001	214-075-150-001	Relay, Voltage sensing	212
318-100	130-020-3	Transmitter, Oil Pressure	212
130-020-3	318-100	Transmitter, Oil Pressure	212
APTE-138-100G	318-100	Transmitter, Oil Pressure	212

**BELL MEDIUM**

**Hydraulic**

<b>Part Number</b>	<b>Alternate Part number</b>	<b>Description</b>	<b>Model</b>
204-076-036-005		Master Cylinder assy	212
205-076-058-101	205-076-135-007	Reservoir Assy	212
205-076-135-007	205-076-058-101	Reservoir Assy	212
205-076-135-109	205-076-135-007	Reservoir Assy	212
212-076-006-003	212-076-006-007	Intergrated Valve & Filter assy	212
212-076-006-007	212-076-006-003	Intergrated Valve & Filter assy	212
212-076-006-105	212-076-006-003	Intergrated Valve & Filter assy	212
212-076-007-003		Accumulator	212
212-076-008-001		Valve	212
212-076-010-001	PV3-044-8	Pump	212
212-076-015-001		Check Valve	212
50579	50579-3	Transmitter, Pressure	212
50579-3	50579	Transmitter, Pressure	212
60024	83154	Switch	212
83154	60024	Switch	212
98505-60024	83154	Switch	212
APTE-139-1500SG	50579	Transmitter, Pressure	212
PV3-044-8	212-076-010-001	Pump	212
PV3-044-8A	212-076-010-001	Pump	212
212-076-011-001	212-076-011-101	Pump	212
212-076-011-101	212-076-011-001	Pump	212